


## COLLAPSIBLE COOKING STOVE

## TO USE:


Remove stove from its carrying case and make sure that the brass gas knob with wire handle is turned all the way out, counterclockwise.



Once installed you should hear no gas. If you hear gas, make sure that the gas flow control knob is turned all the way out, counterclockwise.




• Once the arms are in place, ignite the stove by turning the gas flow control knob ½ a turn and press the red button.



## TO TURN OFF:


> Turn the gas flow control knob counterclockwise all the way.




> Screw on the fuel system to the bottom of the burner.



Next rotate all the burner arms out and down, so that the 3 arms make a flat surface to hold any pot or pan.



You can control the heat by the gas flow control knob.



Allow the stove to fully cool before packing up or touching any of the metal components.

